



1 3D Armrest / function key placed under armpad



- Press button to adjust height
- Push arm-pad for Depth adjustment
- Twirl arm-pad for angle adjustment

Armrest to reduce tiredness to arms and shoulders.

2 Sliding seat / Function key located on the right hand side of the mechanism



- Pull out function key at the seat bottom for sliding function

Sliding function to offer effective support for thigh in the most comfort .

3 Height adjustment / Control rod on the right hand side of mechanism



To lower seat, place your full weight on the chair, and engage actuator lever. When the desired height is reached, release the actuator

To raise the seat, shift your weight to your feet. Engage actuator. Chair will rise automatically

4 Tension tilt / Control rod on the right hand side of mechanism



Twirl outward to increase tension



Twirl inward to release tension

Tension tilt offers more secure and comfortable working environment.

5 **Tilt lock in five positions** / Control rod on the left hand side of mechanism



Twirl outward to engage tilt lock



Twirl inward to engage release

Tilt lock allows the user to sit in an upright position for keyboarding, while providing a comfortable rocking/reclining motion during work or break.



6 **Lumbar Support** / At the back of the chair



Pull up or down the lumbar support by both hand at the same time

Lumbar support may result in relief of lower back pain especially in a long working hour.

Height	1160~1240mm
Seat depth	590~630mm
Seat width	650mm
Distance from floor to seat	440~520mm
Backrest width	470mm
Distance from seat to the top of backrest	635~683mm
Width between armrest	470mm
Distance from floor to armrest	600~740mm
From seat to armrest	160~220mm
Tilt angle degree	20°